

Installation Manual

AUDI A6 4DR
AU-A6-4-B-18



COMPONENTS INCLUDED



FIXING CLIPS



CL-M13 x 2



CL-P02 x 2



CL-M03 x 2



CL-W01 x 1



Side Shade Installation

AUDI A6 4DR
AU-A6-4-B-18

COMPONENTS NEEDED:



STEP #1

CLEAN THE AREA WHERE CLIPS ARE TO BE MOUNTED (AS IN STEP 2) WITH THE SURFACE CLEANER SACHET PROVIDED



STEP #2

PRESS THE CLIPS FIRMLY INTO PLACE AND ALLOW TO DRY FOR 20 MINUTES



STEP #3

ATTACH CLIPS ON SHADE EDGES



STEP #4

POSITION THE SIDE SHADES



STEP #5

ATTACH THE SHADES TO THE CLIPS



STEP #6

ENSURE SECURELY FITTED IN PLACE

