


Flexxy measuring guide



How to measure your dog to determine dog crate size:

- L** = Nose to base of tail -> add at the least +7 cm !
- H** = Height at the withers -> add at the least +7 cm !

**In case of doubt, always choose the next larger dog crate.
The mentioned dog breeds are examples only. ALWAYS measure for yourself!**

	Width (cm)	Length (cm)	Height (cm)	Examples (ALWAYS measure for yourself!)	
Flexxy					
XS	34,5	48,3	39,9	Cat or small dog	
S	42,5	65,9	49,6	Fox Terrier, Cocker Spaniel, Beagle	
M	47,8	77,8	65,8	Whippet, American Staffordshire Terrier, Chow-Chow	
M wide	55,6	75,2	64,2	Whippet, American Staffordshire Terrier, Chow-Chow	
L	65	90,2	72,1	Airedale Terrier, Collie, Golden Retriever	
Flexxy double				Two dogs with separation wall 50/50	One dog, separation wall removed
Double S	82,9	66	49,6	2x Dachshund, Pug, Jack Russell Terrier	1x Fox Terrier, Cocker Spaniel, Beagle
Double M	93,5	78	65,8	2x Fox Terrier, Cocker Spaniel, Beagle	1x Whippet, American Staffordshire Terrier, Chow-Chow